






LivePanel®


Mobeye LivePanel Tank




Included




1A




1B




2A




2B




2C




2D




2E



3A




3B



4A

To activate alarm notifications and verify the operation of the alarm module call Mobilane at +31 (0)88 442 08 65.

LED Pattern	Status	Action Required
Flashing green, 1 second on/1 second off	Module not configured	Set at least on telephone number
Flashing green briefly every 3 seconds	Module is on and running on batteries	No action required
On (Green)	Module is on and running on external power supply	No action required
Flashing green, red	Module establishing network connection	Wait until connection is established
Flashing red twice every 3 seconds	No network connection	Restart module. Try again in a different location
Flashing red 3 times every 3 seconds	SIM card error, incorrect PIN code on SIM card, no call credit	Restart the module
Flashes green 3 times	Successful configuration	No action required
Flashes green 5 times	Incorrect configuration	Check SMS command
Flashes red 4 times every 3 seconds	Low battery voltage	Replace both batteries
Flashes green rapidly	Data synchronisation with portal	No action required



4B

